

LG-iPECS

LIP-8024 LIP-8012 HANDSETS



LG-ERICSSON

If you wish to use Telstra *21 Diversion from a single press of a button, you can. (This feature must first be available from your Carrier Network)

Follow the instructions on the page entitled

[HOW TO ADD A PHONE NUMBER TO A FLEX BUTTON](#)

With the following differences

At the point where you're asked to enter CO or select 0 for a line, you MUST select the Line that is your main number, usually line 1 but not always. You can call your main number from a mobile phone while no other calls are in progress, the line that the call comes in on will usually be your main number. This should work for standard Line Hunt or Rotary Group. (Beware, if you have Direct Indial to individual extensions, *21 will divert the entire 100 number range)

At the point where you are asked to enter the Phone Number, just place *21 before the number and # after.

Eg: *210414123456#

You can also add a button with #21# to cancel the diversion.

Back to

[HOW TO ADD A PHONE NUMBER TO A FLEX BUTTON](#)

For an onsite technician click

[PHONE TECHS 2U](#)